



| SCHEDULE OF FIRE PUMPS |                                                                         |    |
|------------------------|-------------------------------------------------------------------------|----|
| SL.NO.                 | DESCRIPTION                                                             |    |
| 1                      | DIESEL ENGINE DRIVEN FIRE PUMP FOR HYDRANT<br>2850 LPM @ 165m/110m HEAD | F2 |
| 2                      | MAIN FIRE HYDRANT PUMP (ELECTRICAL)<br>2850 LPM @ 165m/110m HEAD        | F2 |
| 3                      | JOCKEY PUMP (ELECTRICAL) FOR HYDRANT<br>180 LPM @ 165m/110m HEAD        | F3 |
| 4                      | MAIN FIRE SPRINKLER PUMP (ELECTRICAL)<br>2850 LPM @ 165m/110m HEAD      | F4 |
| 5                      | JOCKEY PUMP (ELECTRICAL) FOR SPRINKLER<br>180 LPM @ 165m/110m HEAD      | F5 |
| 6                      | FIRE WATER CURTAIN (ELECTRICAL)<br>1620 LPM @ 60m HEAD                  | F6 |
| 7                      | AIR RELEASE VALVE                                                       | AF |
| 8                      | BUTTER FLY VALVE                                                        | DF |
| 9                      | NON-RETURN VALVE                                                        |    |

