
LVL + 99575
MUMTY FLOOR LEVEL
SSL LVL + 94575
TERRACE FLOOR LEVEL
LVL + 90450
11TH FLOOR LEVEL
LVL + 86250
10TH FLOOR LEVEL
LVL + 42050
9TH FLOOR LEVEL
(REFUGE FLOOR)
LVL + 37850
8TH FLOOR LEVEL
LVL + 33650
7TH FLOOR LEVEL
LVL + 29450
6TH FLOOR LEVEL
LVL + 25250
5TH FLOOR LEVEL
(SERVICE FLOOR)
LVL + 20750
4TH FLOOR LEVEL
LVL + 16500
3RD FLOOR LEVEL
LVL + 11700
2ND FLOOR LEVEL
LVL + 6600
1ST FLOOR LEVEL
LVL + 2200
GROUND LEVEL
LVL0000
NGL
LVL - 2200
LOWER GROUND LEVEL
3000
4500
4500
4500